

Cleaning way

Required Time : 15 Mintues

Required Tools : Compressor, Air duster, Brush

If neglected to clean up can cause serious failures or accidents, such as engine burning, fire and mulfunction.

① Skips the grass and dust accumulated on the machine with compressed air.


※ Also see manual, the air cleaner cleaning way

The cleaning operation should be done with the engine stopped. Carefully clean entry ports around the engine, especially around muffler or HST cooling air.

Around Muffler



Muffler Piping



Engine Cooling Air



Rotary Cover Uper part



HST Cooling Air Intake



Mass of Grass around Tire



② Raise right cover and brush the grass and mud in the rotary cover while pouring water

※Do not pour water around engine or HST

During right cover down



During right cover up



※If you don't have equipment, Please contact to local dealer.