

Work Before Long-Term Storage

Required Time : 15 Mintues

Necessary Tool : Manual Pump, Grease gun, and Air gauge

If machine do not perform the appropriate work before long-term storage, may engine failure or may not work properly during uses.

① Clean Machine

Additional Materials : See Cleaning Methods

② Please Grease Up

Additional Materials : Please See How to Grease Up and Pour Oil.

③ Check The Tire Air Pressure

Additional Materials : Please Check Tire Air pressure

④ Remove The Remaining Fuel From The Airframe

Work in a place where the airframe is suuiciently cold and the ventilation is good and there is no fire or burnable goods nearby.



- Use the manual pump to return the fuel in The fuel tank to carring can.

- ※Do not use electric pump.

- ※The kerosene polytank deforms gasoline.

- Use a carrying can for gasoline.

- ※Be careful of static electricity.

- Keep the remaining fuel running untill the engine stops.

- ※Be careful to turn off the key switch.

- Then close the fuel cock.

- Please refer to the attached fuel cock location.

⑤ Keep it in well-ventilated roofed place.

Please make sure around engine and muffler cover is cool enough.

⑥ Next use, refuel with fuel within one month after purchase.

If gasoline is left for more than one month, it will start to deteriorate. Deteriorated fuel casuses engine failure.

- ※Please consult with your local gas station to dispose of waste fuel.

- ※If you do not have tools and equipment, please contact to local delaer.